

# Hardware

## Documentation

Version 1.00  
(03.08.2012)



# NetDCU-SINTF-14


© by F & S Elektronik Systeme GmbH 2012



# History

Date	V	Platform	A,M,R	Chapter	Description	Au
03.08.2012	1.00	NetDCU-SINTF-14		*	New document	TM

V      Version  
A,M,R    Added, Modified, Removed  
Au      Author





# Table of Contents

About this document

History

Table of contents

1.	<a href="#">Introduction</a>	1
2.	<a href="#">Mechanical dimension</a>	2
3.	<a href="#">Connector layout</a>	3
4.	<a href="#">Interface and signal description</a>	4
4.1	<a href="#">(J1)Power Supply</a>	4
4.2	<a href="#">Ethernet</a>	5
4.2.1.	<a href="#">LAN1</a>	5
4.2.2.	<a href="#">LAN2</a>	5
4.3	<a href="#">CAN Interface</a>	6
4.3.1.	<a href="#">CAN1</a>	6
4.3.2.	<a href="#">CAN2</a>	6
4.4	<a href="#">Serial Port</a>	7
4.4.1.	<a href="#">COM1</a>	7
4.4.2.	<a href="#">COM2</a>	7
4.4.3.	<a href="#">COM3</a>	8
4.5	<a href="#">Display Interface</a>	9
4.5.1.	<a href="#">TTL</a>	9
4.5.2.	<a href="#">VGA</a>	9
4.6	<a href="#">Audio Interface</a>	10
5.	<a href="#">Appendix</a>	11



# 1 Introduction

This document does describe the mechanical and electrical informations for the F&S NetDCU-SINTF-14 Startinterface. Please also refer the design guide by using this module for your application.

# 2 Mechanical dimension





Figure 1: mechanical dimension

# 3 Connector layout



# 4 Interface and Signal description

## 4.1 (J1) Power Supply




Figure 1: Power supply J1A

J1A Power Supply				
Pin	Signal	Pin on NetDCU J1 (4 Pin)	Pin on NetDCU J1 (8 Pin)	Pin on NetDCU J1 (26 Pin)
1	V <sub>CFL</sub>	1	1	1
2	+5V ±5% DC power	2	3, 4	9, 21, 22
3	V <sub>BAT</sub> Input for RTC (+3V...+3,6V DC)	3	5	23
4	GND	4	7, 8	10, 25, 26

## 4.2 Ethernet

### 4.2.1 LAN1

J1B LAN1			
Pin on RJ45	Signal	Pin on NetDCU9/10 J2 (14 Pin)	Pin on NetDCU14 J1 (26 Pin)
1	TX+ (Transmit Data)	8	7
2	TX- (Transmit Data)	7	8
3	RX+ (Received Data)	2	1
4	NC		
5	RX- (Received Data)	1	2
6	NC		
7	NC		
8	NC		

### 4.2.2 LAN2

J1C LAN2			
Pin on RJ45	Signal	Pin on NetDCU9/10 JX (XX Pin)	Pin on NetDCU14 J1 (26 Pin)
1	TX+ (Transmit Data)	-	17
2	TX- (Transmit Data)	-	18
3	RX+ (Received Data)	-	15
4	NC	-	
5	RX- (Received Data)	-	16
6	NC	-	
7	NC	-	
8	NC	-	

## 4.3 CAN Interface




Figure 2: CAN transceiver

### 4.3.1 CAN1

J1D CAN1		
Pin	Signal	
1	-	
2	GND	
3	CAN-L	connected to PCA82C250
4	CAN-H	connected to PCA82C250
5	GND	
6	-	
7	-	
8	-	
9	-	
10	-	

A 120R termination resistor can be connected to the CAN lines with Jumper JP3.

### 4.3.1 CAN2

J1E CAN2		
Pin	Signal	
1	-	
2	GND	
3	CAN-L	connected to PCA82C250
4	CAN-H	connected to PCA82C250
5	GND	
6	-	
7	-	
8	-	
9	-	
10	-	

A 120R termination resistor can be connected to the CAN lines with Jumper JP4.

## 4.4 Serial port




Figure 3: 2x 9Pol. SubD connector

### 4.4.1 COM1

J1F COM1			
Pin	Signal	Pin on NetDCU9/10 J2 (14 Pin)	Pin on NetDCU14 J1 (26 Pin)
1	-	-	-
2	RXD	3	4
3	TXD	5	6
4	-	-	-
5	GND	GND	GND
6	-	-	-
7	RTS	4	3
8	CTS	6	5
9	-	-	-

### 4.4.2 COM2

J1F COM2			
Pin	Signal	Pin on NetDCU J5 (16 Pin)	Pin on NetDCU J5 (26 Pin)
1	-	-	-
2	RXD	12	12
3	TXD	14	14
4	-	-	-
5	GND	GND	GND
6	-	-	-
7	-	-	-
8	-	-	-
9	-	-	-

## 4.4.3 COM3




Figure 4: 1x 9Pol & 1x15Pol Connector

J8 COM3			
Pin	Signal	Pin on NetDCU9/10 J7 (26 Pin)	Pin on NetDCU14 J5 (26 Pin)
1	-	-	-
2	RXD	9*	12*
3	TXD	10*	14*
4	-	-	-
5	GND	GND	GND
6	-	-	-
7	-	-	-
8	-	-	-
9	-	-	-

\*To use COM3 make sure that jumper R13 and R14 are mounted. In this case jumper R5 and R6 are not mounted. By default R13 and R14 are mounted.

## 4.5 Display Interface

### 4.5.1 TTL

All pins of the display connector are connected to the respective pins of the NetDCU. See NetDCU documentation for Pin functions.

### 4.5.1 VGA





Figure 4: 1x 9Pol & 1x15Pol Connector

J8 VGA			
Pin	Signal	Pin on NetDCU9 J3 (34 Pin)	Pin on NetDCU14 J3 (48Pin)
1	ARED	43	43
2	AGREEN	44	44
3	ABLUE	45	45
4	NC		
5	GND	GND	GND
6	GND	GND	GND
7	GND	GND	GND
8	GND	GND	GND
9	NC		
10	GND	GND	GND
11	NC		
12	NC		
13	ARHSYNC	46	46
14	ARVSYNC	47	47
15	NC		

## 4.6 Audio Interface



# 5. Appendix

## Important Notice

The information in this publication has been carefully checked and is believed to be entirely accurate at the time of publication. F&S Elektronik Systeme assumes no responsibility, however, for possible errors or omissions, or for any consequences resulting from the use of the information contained in this documentation. F&S Elektronik Systeme reserves the right to make changes in its products or product specifications or product documentation with the intent to improve function or design at any time and without notice and is not required to update this documentation to reflect such changes. F&S Elektronik Systeme makes no warranty or guarantee regarding the suitability of its products for any particular purpose, nor does F&S Elektronik Systeme assume any liability arising out of the documentation or use of any product and specifically disclaims any and all liability, including without limitation any consequential or incidental damages. Products are not designed, intended, or authorised for use as components in systems intended for applications intended to support or sustain life, or for any other application in which the failure of the product from F&S Elektronik Systeme could create a situation where personal injury or death may occur. Should the Buyer purchase or use a F&S Elektronik Systeme product for any such unintended or unauthorised application, the Buyer shall indemnify and hold F&S Elektronik Systeme and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, expenses, and reasonable attorney fees arising out of, either directly or indirectly, any claim of personal injury or death that may be associated with such unintended or unauthorised use, even if such claim alleges that F&S Elektronik Systeme was negligent regarding the design or manufacture of said product.